



Quick Start Guide

High Velocity Masking Compound (HVMC)

1 Clean Surfaces



Before applying compound, remove dust, grease and dirt with a cloth and alcohol, or tack cloth.

2 Mix Putty



Combine equal amounts of Part A and Part B and knead together until the putty is light blue and no white remains. This may take up to 3 minutes.

3 Apply, Cure, then Coat



Allow putty to cure for 6-7 minutes at room temperature before trimming and coating.

4 Remove Putty



Putty is easily removed and leaves little or no residue. To remove from holes use a pointed object such as a screwdriver or toothpick.