


Poor Coating Edge Definition

CAUSE OF PROBLEM

Tape edges fail resulting in


- Poor, burnt, or unacceptable edge definition
- Rejected parts
- Need for reworked parts
- Increased labour costs



CAUSE OF PROBLEM


Edges curl and peel away due to:

- Low breaking strength of glass
- Lower abrasion resistance
- Poor heat resistance
- Low tear strength
- Low adhesive strength:
 - face to back
 - to metal



SOLUTION: STRONGEST HIGH TENSILE STRENGTH


Green Belting tapes have industry leading tensile strength!



SOLUTION: STRONGEST ADHESION to METAL




Green Belting tapes have industry leading adhesion to metal!



SOLUTION: STRONGEST FACE-to-BACK ADHESION


Green Belting tapes have industry leading face-to-back adhesion!



SOLUTION

Green Belting Tapes

- High breaking strength
- High abrasion resistance
- High adhesion
- Flame retardant & self-extinguishing
- High performance adhesives hold firmly spray and release cleanly afterward



Part before coating




Post Coating

SOLUTION

Green Belting Tapes

- Perfect coating lines achieved
- Clean removal, no adhesive residue
- No additional machining required



Post Coating, Masking Removed